


STAND FITTING

- ◆ Lay the sensor face down on a firm surface.
- ◆ Push in one side and then the other until they click into position
- ◆ Move up or down for desired viewing angle.



To remove stand to more easily access the battery housing:

- ◆ Flatten stand so it is parallel to the unit
- ◆ Gently squeeze thumb under one side of the stand until it clicks
- ◆ Lift off the base.



BATTERY & PRODUCT DISPOSAL INFORMATION

- ◆ Do not mix products bearing the crossed out bin symbol with your general household waste. For the correct collection and treatment of these products take them to the collection points designated by your local authority.
- ◆ Alternatively contact the retailer who sold you the product.
- ◆ Remember, when you dispose of the thermometer to remove the batteries and dispose of them responsibly.

MAINTENANCE

- ◆ To clean the product, wipe with a soft cloth to remove dust.
- ◆ If the temperature and humidity display is not visible then the battery cells are exhausted & need to be renewed.

UK GUARANTEE

This product is guaranteed free from defects in materials and workmanship for a period of one (1) year. Proof of purchase is required for validity of the guarantee. This guarantee is no longer valid if the damage has been caused by fall, alteration or repair by any unauthorised persons.

This warranty is in addition to, and does not affect, your statutory rights. The product you buy may sometimes differ slightly from illustration.

This product has been manufactured to comply with EC directive 2004/108/EC as amended EN 61000-6-3 & 1: 2007 & RoHS 2002/95/EC

TECHNICAL DATA

Model No:	HGTM-02
Voltage:	3V DC
Batteries:	2 x LR 44
Ref:	HGTM-02/IM/1611
Dims (WxDxH):	57 x 40 x 70mm
Weight:	NW: 60gm GW: 90gm



© 2016 Newton Stovold Associates Ltd
GU8 6AA / www.nsauk.com

NSA^{UK}

DIGITAL HYGROMETER & THERMOMETER

Model: HGTM – 02



www.nsauk.com

Please read this instruction manual before operating and keep safe for future reference.

INTRODUCTION

Congratulations on the purchase of your Digital Hygrometer & Thermometer. Maintaining the correct temperature and humidity levels is beneficial to us and our homes. Room Humidity is best maintained between 45-55%RH where the health risk from viruses, fungi and dust mites are minimised.

If the Hygrometer/Thermometer displays a reading of 45% or less this indicates that you may need a humidifier to increase the moisture content of the air.

If the Hygrometer/Thermometer displays a reading of 55% or more this indicates that you may need a dehumidifier to remove excess moisture from the air.


IMPORTANT SAFETY INSTRUCTIONS

When using any electrically powered product, basic safety precautions should always be followed.

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT.

- ◆ This thermometer is not a toy. Ensure that it is used under adult supervision and kept out of reach of children under 36 months of age.
- ◆ Do not allow children to play with any product packaging, such as plastic bags.
- ◆ Do not mix old and new batteries.
- ◆ Please note that the operating temperature range is between -5°C to 55°C ~ outside this range the display will read LLL or HHH.
- ◆ The operating humidity range is 20%~99%.
- ◆ The temperature and humidity level of the room is not the same in all parts of the room. We recommend that you experiment by placing the unit in various positions to get the most accurate reading.

CONTROLS AND INDICATORS




BATTERY FITTING

Batteries are already installed within the unit ~ to activate simply remove the plastic strip from underneath the battery cover.

TO REPLACE BATTERIES


- ◆ To open the battery cover press down and slide in the direction of the arrow.
- ◆ Insert 2 x LR44 button cell batteries with positive (+) facing up.
- ◆ Then close the battery cover.



N.B. If the unit displays error messages or unusual readings please remove the batteries and re-insert.

INSTRUCTIONS FOR USE

- ◆ After inserting batteries both displays will briefly illuminate and then commence sensing the room conditions.
- ◆ The correct temperature is displayed very quickly.
- ◆ The humidity display will give the humidity level after a few minutes.
- ◆ To turn on the backlight touch both metal contacts on the right hand side of the sensor with your finger.
- ◆ After a few seconds the light will turn off to save power.
- ◆ Remove the batteries of the hygrometer/thermometer if it is not going to be used for a long period.



TO USE MEMORY FUNCTION

- ◆ Press the MEM memory button on the back of the unit.
- ◆ MEM will then be displayed on both the top and bottom half of the LCD displays. This will then start the internal memory function ~ and will record over a period the Min/Max Humidity & Temperature.
- ◆ To review the recordings; press the Min/Max button on the back of the unit. Press once to display the maximum humidity/temperature – MAX will display on the screen. Press Min/Max for a second time to display the minimum humidity/temperature – MIN will display on the screen. Press Min/Max again to display current readings.
- ◆ Note: pressing the MEM memory button twice will reset the internal memory.